

Detailed description of our current products

The modular system concept for expansion of up to 88 / 118 ports

elmeg ICT880 / 880-rack

Now, expansion has become even more flexible with the new VoIP-VPN Gateway module.

Can also be used with analog exchange connections with the 2 POTS or 4 POTS modules.

Expansion options:

- Max. 46 digital exchange line channels (up to 8 external S0, up to 1 S2M)
- Max. 40 digital S₀-channels (up 20 internal S₀)
- Max. 68 digital U_{p0}-channels (up to 34 internal x U_{p0})
- Max. 4 analog exchange line ports
- Max. 44 analog ports
- Max. 4 door terminals (4 bells possible for each terminal)
- Max. 32 alarm inputs (6 per switching contact module and 8 by means of analog ports on the base moduel)
- Max. 12 switching contacts (3 per switching contact module)
- Max. 88/118 ports in total
- USB port and max. two V.24- interfaces

Base module:

- 4 x S₀, switchable between internal/external
- 8 internal a/bn

2 module slots for expansions with:

- 2 internal S₀, 1 S₀ being switchable between internal/external
- 4 internal S₀, 1 S₀ being switchable between internal/external
- 4 x U_{p0} *
- 8 x U_{p0} *
- 4 internal a/b
- 8 internal a/b
- Cordless DECT-system elmeg DECT400 (1can be used)
- VoIP-VPN-gateway (1 can be used)

Detailed description of our current products

(*a U_{p0} system telephone or an U_{p0}/S₀- converter is required for each U_{p0})

and 2 slots for:

- S_{2M}-module (1x can be used)
- 2 POTS-module (connection of 2 analog exchange lines, 1 can be used)
- 4 POTS-module (connection of 4 analog exchange lines, 1 can be used)
- Door intercom module (door terminal)
- Switching contact module comprising 6 alarm input/sensors and switching contacts/actuators
- Emergency supply module (emergency supply for a connected and authorized ISDN-phone, 1 can be used)

and also:

- ICT router module slot
- Overvoltage protection module

Extension module elmeg ICT880xt / 880xt-rack:

- 6 U_{p0}, 4 internal a/b

2 module slots for expansions with:

- 2 internal S₀, 1 S₀ being switchable between internal/external
- 4 internal S₀, 1 S₀ being switchable between internal/external
- 4 x U_{p0} *
- 8 U_{p0} * (1 can be used)
- 4 internal a/bn
- 8 internal a/bn

(*a U_{p0} system telephone or an U_{p0}/S₀- converter is required for each U_{p0})

and 2 slots for:

- Door intercom module (door terminal)
- Switching contact module comprising 6 alarm inputs/sensors and switching contacts/actuators

and also:

Overvoltage protection module